



1. With the art facing down, fold the end flaps up and in to almost touch each other and aligned along the fold line.



2. Bring the side wall up and fold it over the two end flaps.



3. Bring the other end flaps up and fold the other side wall over them.



4. Push walls back tight against itself.



5. Lock the corners by pushing the ends onto the lock tabs of the sides.